

Introduction

Your BLUESHAPE V-Plate accessory has been designed as an attachment to be fitted to the back of various professional cameras commonly in use today.

Upon installing the V-Plate, you will be able to power your camera using V-mount batteries like BLUESHAPE BV range or similar.

Below you will find pictorial step by step instructions on how to mount your V-plate on the following cameras:

- Sony and Ikegami
- JVC and Philips
- Panasonic

Features and Specifications

D-TAP socket connector for 13.8V / 70 Watt maximum DC output.

Dimensions 82W x 141(H) x 25(D)


Weight: 100 grams (without metal base)

225 grams (with metal base)


Accessories supplied:

- 1 x rubber gasket
- 1 x metal base plate
- 1 x complete screw set containing:
 - 6 x M3 round headed black
 - 6 x M3 countersunk black
 - 2 x M3 round headed silver + washers
- 1 x Instruction manual


Sony and Ikegami Cameras




Step 1




Step 2




Step 3



Step 4









Step 5



Step 6

Panasonic cameras



Philips and JVC cameras

